


OT-1137 Amcon Spring Hinge Assembly Tool



Maintaining

In case the pins are broken, use a standard Phillips screwdriver to open from the bottom and replace the new pins.

Phillips screwdriver not included.



Spring Hinge Assembly Tool

140x94x48mm 425g

